

48	47	49	46	45
44	43		42	41
40	39		38	37
36	35		34	33
32	31		30	29
28	27		26	25

dveře

20	19
16	15
12	11
8	7
4	3

dveře

24	23
22	21
18	17
14	13
10	9
6	5
2	1

řidič

BOVA | SETRA


